

## TASK RANGE

### EXTRA HIGH BACK

<b>NS40</b>	non tilt seat
<b>NS45</b>	tilt seat
<b>NS46</b>	3 paddle mech

NS46M2S5 shown



### HIGH BACK

<b>NS30</b>	non tilt seat
<b>NS35</b>	tilt seat
<b>NS36</b>	3 paddle mech

NS36M2 shown



### MEDIUM BACK

<b>NS20</b>	non tilt seat
<b>NS25</b>	tilt seat
<b>NS26</b>	3 paddle mech

NS20 shown



A5  
Height adjustable arm



A14  
Loop arms

### DRAFTING

<b>NS20D3</b>	non tilt seat
<b>NS26D3</b>	3 paddle mech

NS20D3 shown



L6



Not all models have AFRDI certification. AFRDI certificates for select models available upon request.

DIMENSIONS	Back Size	Seat Size	Height
	Extra high 495 W x 580 H High 444 W x 500 H Medium 435 W x 400 H	500 W x 460 D	Typist / Clerical 450 - 580 Drafting standard 560 - 760 Drafting high lift 630 - 890
OPTIONS	Option codes must be placed in alphabetical order after chair code.  See page 12 for option details	A14 - Standard loop arms A5 - Height adjustable arms B1 - Polished aluminium base C1 - Brake castors (carpet floors) C2 - Brake castors (hard floors)	C5 - Glides D1 - Aluminium footing /Standard drafting D2 - Aluminium footing /High Lift drafting D3 - Black plastic footing /Standard drafting D4 - Black plastic footing /High lift drafting
		E - Ergosit seat cushion M2 - Ratchet mechanism S5 - Large seat (515W x 480D) S6 - Extra large seat (560W x 500D) SS - Slide seat option	

# www.sturdy.com.au OPTIONS

## TASK RANGE

Option codes must be placed in alphabetical order after chair code.



A5  
Height adjustable arm



A14  
Loop arm



B1  
Polished aluminium  
base



C1  
Brake castors  
(carpet floors)



C2  
Brake castors  
(vinyl floors)




C5  
Glides



D1 & D2  
Aluminium footring



D3 & D4  
Black plastic footring



E  
Ergosit seat cushion



M2  
Ratchet mechanism



S6  
Larger seat option




### SLIDE SEAT INSTRUCTIONS

The Slide Seat mechanism allows the seat to slide forward increasing the seat depth by 50mm. It offers 5 locking positions.

As depth between the back and seat increases it allows larger people more comfort.

To operate simply lift the handle and slide the seat forward or backward to adjust into a one of the 5 locking positions. The mechanism should find each locking position without any force necessary.



Sturdy Framac pursue a policy of continuous improvement and reserve the right to introduce modification when required and to withdraw models without previous notification.

Sturdy Components Pty Limited trading as  
**Sturdy Framac**  
www.sturdy.com.au

95 Gow Street, Padstow  
NSW 2211, Australia  
Telephone 02 9790 3500  
Facsimile 02 9707 1081  
email sales@sturdy.com.au

